

How to Install a Coiled Spring Pin

by Jeff Greenwood, Product Sales Engineer SPIROL International Corporation

Coiled Pins were designed with assembly in mind. Compared to other pins, their square ends, concentric chamfers, and lower insertion forces make them ideal for easy installation. Additionally, Coiled Pins can accommodate wider hole tolerances than any other pin because they compress during installation and conform to the shape of the hole. All in all, Coiled Pins are the easiest type of pin to install and are designed to be serviceable.

The Coiled Pin's nominal diameter represents the recommended hole size for the product into which they are being installed. Coiled Pin design guidelines will provide the recommended hole tolerance range. The Coiled Pin is designed so that the pre-installed diameter is greater than the hole size, and the chamfer diameter is smaller than the hole. During installation, the swaged chamfer helps align the Coiled Pin with the hole and facilitates compression of the coils as it is being driven into position.



INSTALLATION OPTIONS

Most manufacturers prefer to use a hammer when only a handful of prototype assemblies are needed. However sometimes, particularly when the pins are too small to hold while hammering into the hole, they may opt to use a pin driving chuck so that they don't have to hold onto the pin while the pin is being inserted. Automatic pin inserters are preferred for high production volumes because they provide a significant return on investment (ROI) over time. Additionally, automatic pin inserters are preferred for small diameter pins that are difficult to handle.

INSTALLATION METHOD COMPARISON - COILED SPRING PINS			
	Hammer	Manual Install w/ Pin Driving Chuck Press / Air Hammer	Automatic Pin Inserter
Ease of assembly	Good	Better	Best
Prototyping			
High volume production			
Small diameter pins		V	V .
Critical alignment		√ .	√ .
Critical insertion depth		✓	
Poka-yoke			
Assembly cycle time			

Hamme

The simplest Coiled Pin installation method is to use a hammer. First, align the Coiled Pin up to the hole by hand. Next, simply hammer the Coiled Pin into the hole as if it was a nail. Drive the pin to the desired insertion depth and be careful not to damage the host.

Using a hammer is great for prototyping a handful of assemblies or trying out a Coiled Pin for the first time. However, this installation method is not recommended for short pins or pins with small diameters because it can be difficult to hold these pins in place by hand.



Manual Press or Air Hammer with Pin Driving Chuck

Coiled Pins can be installed manually with a press or air hammer by using a pin driving chuck. First, secure the pin driving chuck into the press or air hammer. Next, manually insert the Coiled Pin into the end of the driver. Then place the exposed end of the pin into the hole and complete the installation by advancing the press handle or actuating the air gun.

Presses and air hammers with pin chucks allow for better axial alignment, control, and quicker cycle times compared to a hammer. These are great solutions for small to medium volume production. Additionally, pin driving chucks are cost-effective and versatile tools that allow manufacturers to control alignment and insertion depth. Furthermore, the chuck will hold the pin securely in place prior to and during installation. The pin driving chuck has an internal punch with a diameter smaller than the hole but greater than the pin's chamfer diameter. This is critical for effective installation.





Automatic Installation Equipment

Automatic pin inserters are ideal for efficient, high volume production. Automatic inserters are completely self-contained. The fastener is oriented in a vibratory feeder and fed to a shuttle mechanism that positions the fastener directly underneath the insertion quill. The shuttle is mounted on a retracting mechanism that positions the pin exit bushing as close to the assembly as possible for insertion, then retracts for unobstructed loading and unloading.

The installation steps with an automatic pin inserter are simple. The operator will load the assembly onto the fixture, activate the machine to insert the pin, and then remove the assembly from the fixture. Periodically the supply of pins in the feeder bowl must be replenished. The operator does not need to handle the pins throughout any part of the installation process as he/she simply has to pour the pins from the shipping container directly into the feeder bowl as required.

There are many add-on features available to customize the automatic inserter to suit the manufacturer's needs such as: adjustable work station, infrared safety light curtain, force monitoring, distance monitoring, part presence sensing, rotary index tables, feeder bowl level monitoring, drilling and pinning combination, multiple pin insertion per cycle, etc. The feeder bowl can also be designed to sort out errant product or debris.

ADDITIONAL CONSIDERATIONS

Fixturing

Fixtures are designed to hold, support, and align components during installation. This is a critical element to the performance of the installation equipment and therefore the quality of the final product. Effective fixturing also improves cycle times, reduces the risk of scrapped assemblies, and poka-yokes the beginning of the assembly process.

Spring-Loaded Alignment Pin

The use of a spring-loaded alignment pin is recommended for assemblies with through-holes to ensure alignment is maintained between the pin and the holes of the assembly components throughout the entire installation process. A spring-loaded alignment pin is fixed on the installation table and is used for alignment of the assembly prior to and during installation. Spring-loaded alignment pins (also known as locating pins) have spring mechanisms so they retract as the pin is inserted into the assembly as shown in *Figure 1*. If the fixture used the periphery of the assembly components as datums rather than a simple disappearing pin, the manufacturer would have to hold tighter tolerances on the parts to maintain proper alignment. This would result in higher manufacturing costs without adding any value over using a disappearing pin for assemblies with through-holes.




Figure 1

SPIROL Innovative fastening solutions. Lower assembly costs.



Please refer to www.SPIROL.co.uk for current specifications and standard product offerings.

SPIROL Application Engineers will review your application needs and work with you to recommend the optimum solution. One way to start the process is to visit our Optimal Application Engineering portal at SPIROL.co.uk.

Technical Centres

Europe SPIROL United Kingdom

17 Princewood Road Corby, Northants NN17 4ET United Kingdom Tel. +44 1536 444800 Fax. +44 1536 203415

SPIROL France

Cité de l'Automobile ZAC Croix Blandin 18 Rue Léna Bernstein 51100 Reims, France Tel. +33 3 26 36 31 42 Fax. +33 3 26 09 19 76

SPIROL Germany

Ottostr. 4 80333 Munich, Germany Tel. +49 89 4 111 905 71 Fax. +49 89 4 111 905 72

SPIROL Spain

08940 Cornellà de Llobregat Barcelona, Spain Tel. +34 93 669 31 78 Fax. +34 93 193 25 43

SPIROL Czech Republic

Sokola Tůmy 743/16 Ostrava-Mariánské Hory 70900 Czech Republic

Tel/Fax. +420 417 537 979

SPIROL Poland

ul. Solec 38 lok. 10 00-394, Warszawa, Poland Tel. +48 510 039 345

Americas

SPIROL International Corporation

30 Rock Avenue

Danielson, Connecticut 06239 U.S.A. Tel. +1 860 774 8571 Fax. +1 860 774 2048

SPIROL Shim Division

321 Remington Road Stow, Ohio 44224 U.S.A. Tel. +1 330 920 3655 Fax. +1 330 920 3659

SPIROL Canada

3103 St. Etienne Boulevard Windsor, Ontario N8W 5B1 Canada Tel. +1 519 974 3334 Fax. +1 519 974 6550

SPIROL Mexico

Avenida Avante #250 Parque Industrial Avante Apodaca Apodaca, N.L. 66607 Mexico Tel. +52 81 8385 4390 Fax. +52 81 8385 4391

SPIROL Brazil

Rua Mafalda Barnabé Soliane, 134 Comercial Vitória Martini, Distrito Industrial CEP 13347-610, Indaiatuba, SP, Brazil Tel. +55 19 3936 2701 Fax. +55 19 3936 7121

Asia SPIROL Asia Headquarters **Pacific**

1st Floor, Building 22, Plot D9, District D No. 122 HeDan Road Wai Gao Qiao Free Trade Zone Shanghai, China 200131 Tel. +86 21 5046 1451 Fax. +86 21 5046 1540

SPIROL Korea

160-5 Seokchon-Dong Songpa-gu, Seoul, 138-844, Korea Tel. +86 21 5046-1451 Fax. +86 21 5046-1540

email: info-uk@spirol.com